



Silicone and Adhesive Remover - SAR

Directions For Use

As a rule of thumb, Re-mov® SAR works on products which do not harden, i.e., most caulks, contact adhesives, labels, decals, tape residue, gum, sap, tar. Hardened products such as Super Glue, two-part epoxies, urethane floor coatings and varnishes cannot be removed with Re-mov® SAR.

Caulking

For silicone, polyurethane, and polysulfide caulks, cut away any excess caulking. Apply Re-mov® SAR onto the edge(s) of the bond area with a putty knife or scraper. The product will work its way under the caulk to release the bond from the substrate. If residue remains, simply re-spray the area and wipe it clean with a terry type cloth.

Re-mov® SAR will not affect the adhesion of any caulking which may be inadvertently wetted unless edges are specifically worked underneath. Either wipe dry or allow Re-mov® SAR to evaporate.

Contact Cement/Glue/Liquid Nails™ / mirror mastics

Coat the area and soak for several minutes. The longer it remains on the adhesive, the easier your job becomes.

Wipe the area with a clean cloth. If any residue remains, repeat the first step. When using Re-mov® SAR for carpet or headliners, spray the surface heavily, wait at least 15 minutes and test a portion of the item to be removed. If the item remains secure, re-apply and wait an additional 15 minutes before removing the item. With Liquid Nails™ if wet: just spray and wipe, if dry: spray and let stand for 30 minutes minimum then pick up Liquid Nails™ residue and dispose of.

Uncured Polyurethane Expanding Foams

Spray the contaminated area and wipe the area with a clean cloth. Foam will dissolve. Note, once the foam has cured [6 hrs. plus] the Re-mov® SAR will not remove the residue.

Tapes, including Packaging, Duct tape, HB and UHB and Labels/Stickers/Decals/Pinstriping/Protective Film

Spray the item to be removed and allow to soak for one minute. Re-mov® SAR will penetrate from the edges inward. Use a sharp-edged, flexible object to create a viable fringe of material to grab onto and re-apply. Slowly begin pulling away the established edge from the substrate while applying additional spray as needed when tension occurs. It should pull away with ease.

Gum

To remove gum from carpets, clothing or fabric spray and allow to soak for one minute. Rub the area with your fingers or stiff nylon brush. As gum clumps, remove with a clean dry cloth.

Sap/Tar/Grease/Oil Sap, Tar

Grease and Oil will readily dissolve in Re-mov® SAR, just spray, wait, and wipe.

Safe to use on the following surfaces:

Glass, Reflective glass, Mirrors, Plexiglas / polycarbonates, most plastics, fiberglass / gel-coat

Wood: furniture, varnished wood, urethane coated wood, powdered coat, protective films or painted surfaces

Stone surfaces / cultured marble / Tiles, Formica, Corian®, Ceramics, Enamel and Porcelain surfaces

Most Carpets, fabrics, most vinyl and upholstery, clothing, metals, and tools

*** Re-mov® SAR will remove any adhesive in a semi-malleable state.**